



RELEASED  
18.05.10

DAS  
28  
9-89

PPP

Part Number	D350-822-013
Description	PA100 PUREair Provisions

Box Part Number		Dimension	41 x 29 x 14
Other Packaging			
Logo Decals			

### Packaging Instructions and Decal Placement

#### D350-822-013

Place plywood and cardboard on each side of the box.

Apply label D2729-4 on QB21310 transition duct. Place all QB kits in bottom of box. Put 2 pieces of S6438 foam between QB21308 filter. Place one more S6438 foam on top. Put hardware in a Duct bag and place it and the rest of the parts into the box. Put more bubble wrap to prevent movement inside box. Apply wedge along outside length of box. Apply label D2729-3 as per instructions in QSI 01.

D2729-4

1270 ABERDEEN ST. HAWKESBURY ON, CANADA K6A 1K7 TEL: 1-613-632-5200 www.dartaerospace.com			
PATENT	N/A	CHG	CHG002
P/N	D350-822-013	STC	SH14-14
DESC.	PA100 PUREair Provisions	STC	SR03538NY
LOT	SXXXXXX	STC	
MODEL	AS350 / EC130	STC	
TC APPROVAL # 09-89      MADE IN CANADA      D2729-4			

D2729-3

		<b>Dart Aerospace Ltd.</b> 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
<b>PA100 PUREAIR PROVISIONS</b>		
P/N: D350-822-013		CHG002
S/N: SXXXXXX		

Revision: B  
Date: 18.05.03

DAS  
16  
9-89  
18/05/14